

Code Reader Group Catalog



Total solution from recognition to print quality verification

1D / 2D Symbols and Direct Part Marks

Linear (1D) barcodes have been in commercial use since the 1970s and are the most common symbologies used for automatic identification. Increasing numbers of manufacturers are using two-dimensional (2D) symbols, such as Data Matrix, that offer greater placement flexibility and increased data capacity.

Machine-readable symbols generally fall into the categories of linear barcodes, stacked symbols, 2D symbols and Optical Character Recognition (OCR) fonts. A few examples of each are shown below (symbologies are not to scale).

OMRON Microscan provides fast, reliable reading solutions for 1D and 2D Symbology Standards in the right and OCR. Our products read any linear barcodes or 2D symbols printed or marked by any means, and verify them to industry standards.

LINEAR BARCODES









Interleaved 2 of 5



STACKED SYMBOLOGIES





GS1 DataBar (Stacked)





2D SYMBOLOGIES











1D and 2D Symbology Standards

- ■ISO / IEC 15416 1D Print Quality Standard
- ISO / IFC 15415
 - 2D Print Quality Standard
- Automotive Industry Action Group: AIAG B-4 Parts Identification and Tracking
- U.S. Department of Defense: IUID MIL-STD-130 Permanent and Unique Item Identification
- Electronics Industry Association: EIA 706 Component Marking
- Clinical / Laboratory Standards Institute: AUTO2-A2 Bar Codes for Specimen Container Identification
- ISO / IEC 16022 International Symbology Specification
- ISO / IEC 15434 Symbol Data Format Syntax
- Society of Aerospace Engineers: AS9132 Data Matrix Quality Requirements For Part Marking
- AIM DPM / ISO 29158 Direct Part Mark Quality Guideline

NOTE: Symbologies on this page are not shown to scale and are not intended for testing purposes.

OCR FONTS

OCR-A

1234ABCD 1234ABCD 12341111

Alphanumeric Alphanumeric (+4 currency char.) (+4 currency char.)

OCR-B

MICR E-13B

Numeric (+4 special char.)

SEMI M12 1534BCD

Alphanumeric (+4 currency char.)

DIRECT PART MARKS

Direct part marks (DPM) are typically 2D Data Matrix symbols permanently marked by such methods as dot peen or laser / chemical etch onto substrates including metal, plastic, rubber or glass. OMRON Microscan offers a comprehensive family of readers and verifiers with illumination and decode algorithms specifically designed for difficult direct part marks.



Thermal print on foil



Dot peen on metal



Laser etch on meta



Inkjet on ABS plastic

Barcode Verification and Label Inspection

Legible, accurate barcodes and text have never been more important than they are today. Inconsistencies in print quality can lead to process inefficiencies and downtime; unreadable barcodes may require re-labeling, re-scanning, or even manual entry of critical information by a human operator.

Inconsistent quality may also result in expensive vendor noncompliance fines and other penalties, plus damage the labeled product's perceived quality.

Readability of barcodes is determined by how well a barcode reader can decode the data stored in the symbol.

Understanding the primary reasons for decoding failures can save operators valuable time and effort when diagnosing reading issues. Once the cause of barcode unreadability is defined, it can be addressed by taking simple, preventative measures.

OMRON Microscan's barcode verifiers are embedded solutions that include camera, software, and precision illumination specifically designed for the verification of 1D / 2D codes and direct part marks to ISO / IEC standards.

Benefits of Barcode Verification Systems


- Comply with symbol quality industry standards and directives
- Maximize efficiency of your manufacturing process
- Control quality in real time as you verify the output from your printer or code marking equipment
- Minimize returned goods due to bad labels
- Increase customer satisfaction
- Produce informative verification reports

THE IMPORTANCE OF VERIFICATION

Automated data capture is critical to a company's success, and the results of scanning failure can have a serious impact. Without verification, bad barcodes are not identified until they are unreadable. By the time a bad barcode is identified, thousands of poor-quality barcodes may have already escaped down the line. With verification, bad barcodes are prevented from being applied to the product, eliminating the chance for future failures.

WITHOUT VERIFICATION


Barcode Quality Over Time: Using a Reader to Check Quality



Number of Parts Marked / Labeled

WITH VERIFICATION

Barcode Quality Over Time: Using a Verification Solution to Check Quality



Number of Parts Marked / Labeled

A wide range of products to suit your application



1D / 2D Code Recognition



Laser Barcode Readers

From small products for embedded OEM applications to rugged readers for industrial manufacturing environments, OMRON Microscan offers a wide range of quality products to read linear barcodes and stacked symbols, with features such as high-speed decoding, wide field of view, symbol reconstruction and aggressive decode algorithms.









MS-3 series

Compact raster laser barcode reader offers high-performance decoding and wide scan angle at close range.

QX-830 series

Compact laser barcode reader features QX platform, symbol reconstruction and Ethernet protocols.

QX-870 series

Programmable sweeping raster laser barcode reader with QX platform, symbol reconstruction and Ethernet protocols.

Read Range	51 to 254mm	25 to 762mm	25 to 762mm
Scans / Second	Up to 1000	300 to 1400	300 to 1400
Power	5 VDC	10 to 28 VDC	10 to 28 VDC
Sensor	Laser diode	Laser diode	Laser diode
IP Rating	IP54	IP54	IP65
Connectivity	RS-232, RS-422 / 485 (up to 115.2k), Keyboard Wedge, USB	RS-232, RS-422 / 485 Ethernet TCP / IP or EtherNet / IP™	RS-232, RS-422 / 485 Ethernet TCP / IP or EtherNet / IP™

P.12 P.6 **P.18**

Handheld Code Readers

OMRON Microscan's handheld code readers feature the latest technology for decoding 1D and 2D symbols. From simple data tracking for inventory control to aggressive reading of the toughest direct part marks, we have a handheld solution for various track, trace, and control applications. These compact designs feature durable, shock-resistant enclosures that are disinfectant-ready.











HS-360X series

V430-F series

P.24

P.30



Print Quality Verification



Barcode Verification Systems

OMRON Microscan's LVS® Barcode Verifiers are fully-integrated off-line solutions designed for the verification of 1D and 2D symbols and direct part marks to application standards such as GS1, HIBC, USPS and ISO / IEC 15415 / 15416. Barcode Verification Kits offer flexible integration options for offline to symbology standards or user-defined parameters.





LVS-9510 series

LVS-958□ series

All-in-one desktop verifier for off-line ISO / IEC barcode All-in-one handheld verifier for flexible verification of multiple printed 1D / 2D verification.

symbols and direct part marks (DPM). Can be used with a tablet for portability.

1D / 2D	✓	✓
DPM		✓
GS1 Data	✓	✓
GS1 Certified Manage	✓	✓
Permissions	✓	✓
Field of View	Varies by model	Standard: Horizontal 76 mm, Vertical 57 mm DPM: 44×44 mm DPM-HD: 33×33 mm

P.38,42 P.34

OTHER FEATURES

- GS1 US® and 21 CFR Part 11 compliant-ready
- Verifies to over 20 global application standards and over 30 symbology types
- Enables U.S. FDA UDI (Unique Device Identification) compliance for Medical Device Manufacturers and Labelers
- Provides comprehensive and user-friendly barcode defect analysis to help guide corrections
- Includes a local report archive, as well as an external database interface to provide flexible quality reporting



Laser Barcode Reader

MS-3 series

Ultra-Compact Laser Barcode Reader



The MS-3 laser barcode reader offers the fastest read performance* in embedded compact bar code readers. The wide scan angle of 70 degrees is coupled with ultra-compact size and flexible mounting.

High performance and flexibility make the MS-3 the optimal choice for reliable reading in embedded instruments.

*. Based on Omron investigation in march 2018.

MS-3: At a Glance

- Decodes / second: up to 1000
- Read Range: 51 to 254 mm
- · Wide Scan Angle
- IP54 Enclosure



ESP® Easy Setup Program: Single-point software provides quick and easy setup and configuration of all OMRON Microscan readers.



EZ Button: This performs reader setup and configuration with no computer required.

MS-3: Available Codes

Linear



Please see the Ratings and Specifications for a complete list of supported symbologies.

Compact & Lightweight

44.5 mm square by 21.6 mm tall code reader weighs only 57 g for easy mounting onto robotic equipment or into tight spaces.

High Scan Speed

Adjustable scan speed from 300 up to 1000 decodes per second and OMRON Microscan's world-class decode algorithms ensure accurate reading every time.

Wide Scan Angle

The wide scan angle of over 70 degrees and a factory customizable focal point add up to space savings within your system, allowing greater flexibility with positioning.

Visible Indicators

Illuminated LEDs on top of the code reader provide visual confirmation of the code reader performance.

Real-time Controls

The inputs include a trigger signal, a "new master" input, and a programmable input for resetting counters or releasing outputs. The outputs can be configured to activate upon a variety of conditions including matchcode and diagnostic operations.

Application Examples

- Clinical instruments
- Bank ATMs
- Parking kiosks
- Point-of-sale terminals
- Robotics

Ordering Information

Laser Barcode Readers

Scan mode	Read range	Installation type	Model
Single Line	Low Density	Standard	FIS-0003-0001G
Single Line	High Density	Standard	FIS-0003-0002G
Raster Line	Low Density	Character of	FIS-0003-0003G
Raster Line	High Density	Standard	FIS-0003-0004G
Single Line	Low Density	Right Angle	FIS-0003-0005G
Raster Line	Low Density	Right Angle	FIS-0003-0007G

Accessories

Туре	Model
MS-Connect 210, Connectivity Box with Display	FIS-0210-0001G
Relay Module, 120 VAC, 3 Amp Output, Series 70, Type SM, for MS-Connect 210	98-000013-04
Relay Module, 240 VAC, 3 Amp Output, Series 70, Type SM, for MS-Connect 210	98-000013-05
Relay Module, 24 VDC, 3 Amp Output, Series 70, Type SM, for MS-Connect 210	98-000013-06
Cable, MS-3 to MS-Connect 210, 1.8 m (6 feet)	61-000127-02
IB-3PC Keyboard Wedge / Interface Box	FIS-0001-0030G
IC-3USB Interface Kit, USB to Serial 15-pin	98-000051-01
Converter, IC-332, 24 V / 5 V, Opto I / O for use with IB-131	FIS-0001-0035G
IB-131 Interface Box	99-000018-01
Communication Cable, DB-25 Plug to DB-9 Socket, 1.8 m (6 feet)	61-300026-03
Communication Cable, DB-9 Socket to DB-9 Socket, 1.8 m (6 feet)	61-000010-02
IB-131 Daisy Chain Cable	61-100029-03
Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01

Power Supplies

Туре	Model
Power Supply, 100-240 VAC, +5 VDC, 5-pin Plug, U.S. / Euro Plug	97-000011-01
Power Supply, 100-240 VAC, +5 VDC, 2-pin Plug, U.S. / Euro Plug	97-000011-02
Power Supply, 100-240 VAC, +24 VDC, TRK 3-pin, U.S. / Euro Plug	97-000012-02

Note: Do not use the power supplies or power supply cords indicated in this catalog with any other electric or electronic equipment. When using the MS-3 Series, please use the power supply and power supply cord indicated in this catalog.

Mounting and Connectors

Туре	Model
Mounting Arm / Adapter Kit for MS-3, 101 mm (4 inches)	98-000048-01
Mounting Stand Base Plate Kit	98-000054-01
Mounting Arm Extension Kit for MS-3, 101 mm (4 inches)	98-000053-01
Mounting Arm Extension Kit for MS-3, 76 mm (3 inches)	98-000053-02
Side Mount Bracket for MS-3	98-000060-01
Angle Mount Bracket for MS-3	98-000059-01
Through-Hole Mount Bracket for MS-3	98-000057-02
Extended Right Angle Mirror for MS-3	98-000058-02
Trigger Connector, 4-pin Plug (screw terminal and field wireable for custom wiring into IB-131)	20-610024-01

Ratings and Specifications


Applicable codes		Code 39, Code 128, Interleaved 2 of 5, Codabar, Code 93, UPC / EAN, Pharmacode	
	Scan mode	Single line, fixed raster	
	Scan rate	Adjustable from 300 to 1,000 scans / s, default=500	
Reading	Scan width angle	>70°	
performance	Pitch	±50°	
	Skew	±40°	
	Label contrast	25% min. at 650 nm	
	Interface	RS-232, RS-422 / 485, USB	
Communications	Protocols	Point-to-Point, Point-to-Point w / RTS / CTS, Point-to-Point w / XON / XOFF, Point-to-Point w / RTS / CTS & XON / XOFF, Polling Mode D, Multidrop, User Defined, User Defined Multidrop, Daisy Chain	
	Trigger input	3 to 24 V rated (1 mA at 5 VDC)	
	New Master	3 to 24 V rated (1 mA at 5 VDC)	
I / O specifications	Outputs (1, 2, 3)	5 V TTL compatible, can sink 10 mA and source 2 mA	
	Beeper	Good read, Match/Mismatch, Noread	
	On / Off LEDs	1 status, 1 power, 5 read performance (representing percentage of good decodes)	
Power requirement		5 VDC±5%, 200 mV p-p max. ripple, 260 mA at 5 VDC (typ.)	
Lance Palet	Туре	Semiconductor visible laser diode (650 nm nominal)	
Laser light	Safety class	IEC 60825-1 Class II, 1.0 mW max.	
	Ambient temperature range	Operating: 0 to 50°C, Storage: -40 to 75°C	
Environmental	Ambient humidity range	Up to 90% (with no icing or condensation)	
specifications	Operating life	40,000 hours at 25°C	
	Degree of protection	IP54 (category 2)	
\\\/-:-b+	Standard	Approx. 106 g	
Weight	Right Angle	Approx. 136 g	
Safety standards		FCC, UL/c UL, CE, KC, RCM, EAC, BIS	

HOST CONNECTOR / PIN ASSIGNMENTS High Density 15 Pin D-sub Socket Connector

riigii belisity 131 ii b sub sociaet conficetor				
Pin No.	Host RS-232	Host / Aux RS-232	Host RS-422 / 485	In / Out
1		Power +5 VDC		In
2	TxD	TxD	TxD(-)	Out
3	RxD	RxD	RxD(-)	In
4		Power / Signal (Ground	
5	NC			
6	RTS	Aux TxD	TxD(+)	Out
7	Output 1 TTL ^a			Out
8	Default configuration ^b			In
9	Trigger		In	
10	CTS	Aux RxD	RxD(+)	In
11	Output 3 TTL ^a			Out
12	New Master (NPN)			In
13	Chassis ground ^c			
14	Output 2 TTL ^a			Out
15	NC			

- a. Can sink 10 mA and source 2 mA.
- b. The default is activated by connecting pin 8 to ground pin 4. c. Chassis ground: Used to connect chassis body to earth ground only. Not to be used as power or signal return.

Read Ranges (Unit: mm)




Narrow-bar-width	Read range
0.191 mm	76 to 152 mm
0.254 mm	51 to 178 mm
0.381 mm	51 to 203 mm
0.508 mm	51 to 254 mm

Narrow-bar-width	Read range
0.084 mm	Contact OMRON.
0.127 mm	51 to 79 mm
0.191 mm	43 to 94 mm
0.254 mm	38 to 102 mm

Note: For Right Angle option, subtract 15 mm from read range. Read ranges are based upon optimal scan speed for specific symbol density.

Dimensions (Unit: mm)






Laser Label Indications

This warning label is attached to the laser barcode reader. Never remove this label or place objects in front of it.

System Configurations

Stand Alone (5V)

This is the basic setup for a single MS-3.




No.	Туре	Model
1	MS-3 Laser Barcode Reader	FIS-0003-□□□G
2	IB-3PC Keyboard Wedge / Interface Box	FIS-0001-0030G
3	Power Supply,100-240VAC,+5VDC, 5PIN, USA / EUR Plug	97-000011-01
4	Cable, Communication, DB-9 Socket-to- DB-9 Socket, 6 ft.	61-000010-02
-	Kit, Mounting Arm / Adapter, 4 in., for MS-3	98-000048-01
-	Kit, Mounting Stand Base Plate	98-000054-01


Stand Alone (10-28V)

With MS-Connect 210

This is the basic setup for a single MS-3 and MS-Connect 210.




No.	Туре	Model
1	MS-3 Laser Barcode Reader	FIS-0003-□□□G
2	Connectivity Box A	FIS-0210-0001G
3	Converter, IC-332, 24V / 5V, Opto I / O, for Use with IB-131	FIS-0001-0035G
4	Cable, MS-3-to-MS-Connect 210, 6 ft.	61-000127-02
5	Power Supply (100-240 VAC, +24VDC, TRK 3Pin, USA/Euro Plug)	97-000012-02
6	Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01



	288211	
No.	Туре	Model
1	MS-3 Laser Barcode Reader	FIS-0003-□□□□G
2	Converter, IC-332, 24V / 5V, Opto I / O, for Use with IB-131	FIS-0001-0035G
3	IB-131 Interface Box	99-000018-01
4	Power Supply (100-240 VAC, +24VDC, TRK 3Pin, USA / Euro Plug)	97-000012-02
5	Cable, Communication, DB-25 Plug-to-DB-9 Socket, 6 ft.	61-300026-03
6	Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01
-	Kit, Mounting Arm / Adapter, 4 in., for MS-3	98-000048-01
-	Kit, Mounting Stand Base Plate	98-000054-01

USB




No.	Туре	Model
1	MS-3 Laser Barcode Reader	FIS-0003-□□□G
2	IC-3USB Interface Kit, USB-to-Serial, 15-Pin	98-000051-01
-	Kit, Mounting Arm / Adapter, 4 in., for MS-3	98-000048-01
-	Kit, Mounting Stand Base Plate	98-000054-01

System Configurations

Daisy Chain

A primary code reader is linked directly to the host. Secondary code readers (up to 9) are linked in tandem. Data is sent from the primary code reader directly to the host.



No.	Туре	Model
1	MS-3 Laser Barcode Reader	FIS-0003-□□□G
2	Converter, IC-332, 24V / 5V, Opto I / O, for Use with IB-131	FIS-0001-0035G
3	IB-131 Interface Box	99-000018-01
4	Power Supply (100-240 VAC, +24VDC, TRK 3Pin, USA / Euro Plug)	97-000012-02
5	Cable, Daisy Chain, IB-131	61-100029-03
6	Cable, Communication, DB-25 Plug-to-DB-9 Socket, 6 ft.	61-300026-03
7	Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m.	99-9000016-01
-	Kit, Mounting Arm / Adapter, 4 in., for MS-3	98-000048-01
-	Kit, Mounting Stand Base Plate	98-000054-01

Laser Barcode Reader

QX-830 series

Compact Industrial Laser Barcode Reader



The OX-830 laser barcode reader combines flexible connectivity with high performance decoding capabilities to reliably read 1D barcodes in almost any automation environment. In addition to the Quick Connect System and X-Mode Technology, the QX-830 features IP54 industrial sealing and optional embedded Ethernet protocols.

High performance, simple connectivity, and the highest quality enclosure make the QX-830 an ideal laser barcode reader for any industrial application.

QX-830: At a Glance

- Scans / second: 300 to 1400
- Read Range: 25 to 762 mm
- Optional Embedded Ethernet TCP / IP & EtherNet / IP
- IP54 Enclosure



ESP®Easy Setup Program: Single-point software solution provides quick and easy setup and configuration of all OMRON Microscan readers.



EZ Button: This performs reader setup and configuration with no computer required.



Visible Indicators: Performance indicators include "good read" green flash and LEDs.



QX Platform: Quick Connect system and X-Mode technology combine to provide simple connectivity, networking, and high performance decoding.

OX-830: Available Codes

Linear



Stacked





Please see the Ratings and Specifications for a complete list of supported symbologies.



Ouick Connect System

- Plug and play setup
- · Single or multi-code reader solutions

X-Mode Technology

- · Decodes damaged, poorly printed, or misaligned codes
- Ensures high read rates and throughput

High Performance

Aggressive decoding capabilities allow reliable reading of barcodes out to 762 mm, at up to a 254 mm beam width.

Real-time Feedback

Visible LED indicators on the side of the code reader and a "good read" green flash projecting from the front window provide confirmation of the code reader's performance. The green flash is visible within a complete 360 degree radius from the code reader.

Ethernet Protocols

The QX-830 includes optional embedded Ethernet TCP / IP and EtherNet / IP for high speed communication.

Flexibility

The compact size of the QX-830 allows flexible positioning for a variety of applications.

Application Examples

- · Any industrial environment from light to heavy duty
- Conveyor lines
- Packaging and sortation
- Electronics production
- · Embedded within machinery

Ordering Information

Laser Barcode Readers

Scan mode	Read range	Interface	Model	
	Low Density		FIS-0830-0001G	
Single Line	Middle Density	Serial *1	FIS-0830-0002G	
	High Density		FIS-0830-0003G	
	Low Density		FIS-0830-0004G	
Raster Line	Middle Density		FIS-0830-0005G	
Raster Line	High Density	Density Serial *1		
	Low Density / Plastic Window		FIS-0830-0010G	
	Low Density		FIS-0830-1001G	
Single Line	Middle Density	Serial *2 and Ethernet	FIS-0830-1002G	
	High Density		FIS-0830-1003G	
	Low Density		FIS-0830-1004G	
Destroller	Middle Density	Serial *2 and Ethernet	FIS-0830-1005G	
Raster Line	High Density		FIS-0830-1006G	
	Low Density / Plastic Window		FIS-0830-1010G	

^{*1.} Supports RS-232, RS-422, or RS-485. *2. Supports RS-232.

Accessories

Туре	Model
QX-1 Interface Device	98-000103-02
QX Cordset, Common, M12 12-pin Socket (Screw-On) to M12 12-pin Plug (Screw-On), 3 m	61-000148-02
QX Cordset, Common, M12 12-pin Socket (Screw-On) to M12 12-pin Plug (Screw-On), 1 m	61-000162-02
QX Cordset, Host, Serial, M12 12-pin Socket (Screw-On) to DB-9 Socket, 1 m	61-000153-02
QX Cordset, Host, Serial, M12 12-pin Socket (Screw-On) to DB-9 Socket, 3 m	61-000164-02
QX Cordset, Host, Serial, M12 12-pin Plug (Screw-On) to DB-9 Socket, 1 m	61-000152-02
QX Cordset, Host, Serial, M12 12-pin Plug (Screw-On) to DB-9 Socket, 3 m	61-000165-02
QX Cordset, Host, Ethernet, M12 8-pin Plug (Screw-On) to RJ45, 1 m	61-000160-03
QX Cordset, M12 12-pin Plug to M12 12-pin Socket to DB-25 Plug Turck Connectors	61-000172-02
QX Cordset, M12 12-pin Plug & M12 12-pin Socket to MS-Connect 210, RS-232, 2 m	61-000158-03
QX Cordset, M12 12-pin Plug (Screw-On) to Flying Leads, 3 m	61-000166-02
QX Cordset, M12 12-pin Plug & Socket to IB-131, RS-232, 2 m	61-000159-03
QX Cordset, M12 12-pin Socket to IB-131, RS-232/RS-485, 2 m	61-000159-04
Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01

Power Supplies

Туре	Model
Power Supply, 100-240 VAC, +24 VDC, M12 12-pin Socket	97-000012-01
Power Supply, 100-240 VAC, +24 VDC, M12 12-Pin Plug	97-000012-04

Note: Do not use the power supplies or power supply cords indicated in this catalog with any other electric or electronic equipment. When using the QX-830 Series, please use the power supply and power supply cord indicated in this catalog.

Mounting and Connectors

mounting and connectors	
Туре	Model
Mounting Plate Kit for QX-830 / QX-870	98-500006-01
Right Angle Mirror Kit for QX-830	98-200026-02
Mounting Arm/Adapter Kit for QX-830 / QX-870, 152 mm (6 inches)	98-000016-01
Mounting Arm Extension Kit for all code readers,152 mm (6 inches)	98-000037-01
L-Bracket Kit for QX Series	98-000148-01
Mounting Stand Base Plate Kit	98-000054-01
Trigger Connector, 4-pin Plug (screw terminal and field wireable for custom wiring into IB-131)	20-610024-01

Ratings and Specifications

Applicable codes	Standard	Code 39, Codabar, Code 93, Interleaved 2 of 5, Code 128, PDF417, Micro PDF417, Pharmacode, UPC, GS1 Databar
	Application standards	UCC / EAN-128, AIAG
	Mirror type	Rotating, 10-faceted
	Optional raster mirror image	10 raster scan lines over a 2° arc (or 0.500-inch raster height at 8-inch [203-mm] distance)
	Scan rate	Adjustable from 300 to 1,400 scans / s, default=500
Reading performance	Scan width angle	60° (typ.)
periormance	Pitch	±50° max.
	Skew	±40° max.
	Label contrast	25% min. absolute dark to light differential at 655 nm wavelength
	Interface	RS-232 / 422 / 485 or Ethernet*
Communications	Protocols	Point-to-Point, Point-to-Point w / RTS / CTS, Point-to-Point w / XON / XOFF, Point-to-Point w / RTS / CTS & XON / XOFF, Multidrop, Daisy Chain, User-Defined Multidrop, Ethernet TCP / IP, EtherNet / IP
1/0	Input 1 / Trigger / New Master	Optoisolated, 4.5 to 28 V rated, (13 mA at 24 VDC) New Master is (–) to signal ground
I / O specifications	Outputs (1, 2 & 3)	Optoisolated, 1 to 28 V rated, (Ice < 100 mA at 24 VDC, current limited by user)
Power requirement		10 to 28 VDC, 200 mV p-p max. ripple, 180 mA at 24 VDC (typ.)
	Туре	Laser diode
	Output wavelength	655 nm nominal
Lanca Palat	Beam divergence	0.4 mrad (typ.)
Laser light	Pulse time	40 to 186 μs
	Maximum output	1.75mW
	Safety class	Visible laser: IEC 60825-1 Class 2
	Ambient temperature range	Operating: 0 to 50°C, Storage: -40 to 75°C
Environmental	Ambient humidity range	Up to 90% (with no icing or condensation)
specifications	Degree of protection	IP54
	Operating life	50,000 hours at 25°C
Weight		Approx. 212 g
Dimensions		35 x 65.7 x 87.8 mm (H x D x W)
Safety standards		FCC, UL/c UL, CE, CB, KC, RCM, EAC, BIS
Material (Case)		Aluminum diecast

^{*} Depends on model. See Ordering Information for details.

PIN ASSIGNMENTS

CONNECTOR A M12 12-PIN PLUG





Pin	P	Assignmen

1	Trigger
2	Power
3	Default
4	New Master
5	Output 1
6	Output 3
7	Ground
8	Input Common
9	Host RxD
10	Host TxD
11	Output 2
12	Output Common



Pin Assignment		
1	Trigger	
2	Power	
3	Terminated	
4	Input 1	
5	422/485 TxD (+)	
6	422/485 RxD (+)	
7	Ground	
8	Input Common	
9	TxD / RTS	
10	RxD / CTS	
11	422 / 485 TxD (-)	
12	422 / 485 RxD (-)	

ETHERNET CONFIGURATION


CONNECTOR B M12 8-PIN SOCKET





Pin Assignment

ierminated
Terminated
Terminated
TX (-)
RX (+)
TX (+)
Terminated
RX (-)

Read Ranges* (Unit: mm)








Narrow-bar-width	Read range
0.191 mm	254 to 305 mm
0.254 mm	178 to 406 mm
0.381 mm	152 to 483 mm
0.508 mm	127 to 559 mm
1.02 mm	102 to 762 mm

Narrow-bar-width	Read range
0.191 mm	64 to 140 mm
0.254 mm	38 to 178 mm
0.381 mm	38 to 216 mm
0.508 mm	38 to 279 mm
0.762 mm	25 to 305 mm

Narrow-bar-width	Read range
0.084 mm	Contact OMRON.
0.127 mm	102 to 127 mm
0.191 mm	89 to 171 mm
0.254 mm	82 to 203 mm
0.381 mm	82 to 229 mm

Top 87.8

Dimensions (Unit: mm)






Laser Label Indications


This warning label is attached to the laser barcode reader. Never remove this label or place objects in front of it.

^{*} Ranges based on a Grade A, Code 39 label, at 500 scans per second. Data subject to change.

System Configurations

Stand Alone Configurations







No.	Туре	Model
1	QX-830 Laser Barcode Reader	FIS-0830-□□□□G
2	QX Cordset, Host, Serial, M12 12-Pin Plug (Screw-On)-to-DB-9 Socket, 1 m.	61-000152-02 [*]
3	QX Cordset, Host, Serial, M12 12-Pin Socket (Screw-On)-to-DB-9 Socket, 1 m.	61-000153-02 [*]
4	Power Supply, 100-240VAC, +24VDC, M12 12-Pin Socket	97-000012-01
5	Power Supply, 100-240VAC, +24VDC, M12 12-Pin Plug 97-000012-04	
6	QX Cordset, Host, Ethernet, M8 8-Pin Plug (Screw-On)-to-RJ45, 1 m.	61-000160-03
-	Kit, 6 in. Mounting Arm / Adapter, QX-830, QX-870	98-000016-01
-	Kit, Mounting Stand Base Plate	98-000054-01


^{*} Cordsets available in multiple lengths.

Stand Alone Configurations

With QX-1 or MS-Connect 210









No.	Туре	Model
1	QX-830 Laser Barcode Reader	FIS-0830-□□□G
2	QX-1 Interface Device	98-000103-02
3	QX Cordset, Common, M12 12-Pin Socket (Screw-On)-to-M12 12-Pin Plug (Screw-On), 1 m.	61-000162-02*1
4	QX Cordset, Host, Serial, M12 12-Pin Socket (Screw-On)-to-DB-9 Socket, 1 m.	61-000153-02 ^{*1}
5	Power Supply, 100-240VAC, +24VDC, M12 12-Pin Socket 97-000012-01	
6	QX Cordset, Host, Ethernet, M12 8-Pin Plug (Screw-On)-to-RJ45, 1 m.	61-000160-03*1
7	QX Cordset, M12 12-Pin Plug & M12 12-Pin Socket-to-MS-Connect 210 (RS-232), 2 m. 61-000158-03	
8	Power Supply, 100-240VAC, +24VDC, TRK 3-Pin, U.S. / Euro Plug) 97-000012-02	
9	Connectivity Box	FIS-0210-0001G*2
10	Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01
-	Kit, 6 in. Mounting Arm / Adapter, QX-830, QX-870	98-000016-01
-	Kit, Mounting Stand Base Plate	98-000054-01


^{*1.} Cordsets available in multiple lengths
*2. Refer to MS-Connection page for complete listing of MS-Connection 210 options

System Configurations

Daisy Chain Configurations







No.	Туре	Model
1	QX-830 Laser Barcode Reader	FIS-0830-□□□□G
2	QX-1 Interface Device	98-000103-02
3	QX Cordset,Common,M12 12-Pin Socket(Screw-On)-to-M12 12-Pin Plug(Screw-On), 1 m.	61-000162-02 [*]
4	QX Cordset, Host, Serial, M12 12-Pin Socket (Screw-On)-to-DB-9 Socket, 1 m.	61-000153-02 [*]
5	QX Cordset, Host, Serial, M12 12-Pin Plug (Screw-On)-to-DB-9 Socket, 1 m.	61-000152-02*
6	Power Supply, 100-240VAC, +24VDC, M12 12-Pin Socket 97-000012-01	
7	QX Cordset, Host, Ethernet, M8 8-Pin Plug (Screw-On)-to-RJ45, 1 m. 61-000160-03	
8	Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01
-	Kit, 6 in. Mounting Arm / Adapter, QX-830, QX-870	98-000016-01
-	Kit, Mounting Stand Base Plate	98-000054-01

^{*} Cordsets available in multiple lengths.

Laser Barcode Reader

QX-870 series

Industrial Raster Laser Barcode Reader



M12 Connectors & Optional **Embedded Ethernet**

QX-870: At a Glance

- Scans / second: 300 to 1400
- Read Range: 25 to 762 mm
- Optional Embedded Ethernet TCP / IP & EtherNet / IP
- IP65 Enclosure



ESP®Easy Setup Program: Single-point software solution provides quick and easy setup and configuration of all OMRON Microscan readers.



EZ Button: This performs reader setup and configuration with no computer required.



Visible Indicators: Performance indicators include "good read" green flash and LEDs.



Sweeping Raster: This programmable feature enables the reader for multiple symbols at varying distances and locations



QX Platform: Quick Connect system and X-Mode technology combine to provide simple connectivity, networking, and high performance decoding.

QX-870: Available Codes

Linear



Stacked





Please see the Ratings and Specifications for a complete list of supported symbologies.

The QX-870 laser barcode reader partners the latest technologies in barcode reading and connectivity into an easy to use solution for barcode track, trace and control applications. Simple to set up and deploy, it features a programmable sweeping raster to read multiple codes, in varying locations, even if they are damaged or mis-aligned.

With plug and play setup and the most aggressive decode algorithms available, the QX-870 an ideal laser barcode reader for any industrial application.



Ouick Connect System

- Plug and play setup
- · Single or multi-reader solutions

X-Mode Technology

- · Decodes damaged, poorly printed, or misaligned codes
- Ensures high read rates and throughput

High Performance

Aggressive decoding capabilities allow reliable reading of barcodes out to 762 mm, at up to a 254 mm beam width.

Intelligent Raster

In addition to sweep angle and speed controls, the QX-870 features a programmable raster with intelligent auto framing technology. Advanced software will automatically frame the raster height and width of the laser to match the barcode, allowing selective targeting of codes within a single read cycle.

Ethernet Protocols

The OX-870 includes optional embedded Ethernet TCP / IP and EtherNet / IP for high speed communication.

Application Examples

- · Any industrial environment from light to heavy duty
- Automotive assembly
- Packaging and sortation
- Electronics production
- Embedded within machinery

Ordering Information

Laser Barcode Readers

Scan mode	Read range	Interface	Model
	Low Density	Serial *	FIS-0870-0004G
Curaning Pastor	Medium Density		FIS-0870-0005G
Sweeping Raster	High Density		FIS-0870-0006G
	Low Density / Plastic Window		FIS-0870-0007G
	Low Density	Serial * and Ethernet	FIS-0870-1004G
Sweeping Raster	Medium Density		FIS-0870-1005G
	High Density		FIS-0870-1006G

^{*} Supports RS-232, RS-422, or RS-485.

Accessories

Туре	Model
QX-1 Interface Device	98-000103-02
QX Cordset, Common, M12 12-pin Socket (Screw-On) to M12 12-pin Plug (Screw-On), 3 m	61-000148-02
QX Cordset, Common, M12 12-pin Socket (Screw-On) to M12 12-pin Plug (Screw-On), 1 m	61-000162-02
QX Cordset, Host, Serial, M12 12-pin Socket (Screw-On) to DB-9 Socket, 1 m	61-000153-02
QX Cordset, Host, Serial, M12 12-pin Socket (Screw-On) to DB-9 Socket, 3 m	61-000164-02
QX Cordset, Host, Serial, M12 12-pin Plug (Screw-On) to DB-9 Socket, 1 m	61-000152-02
QX Cordset, Host, Serial, M12 12-pin Plug (Screw-On) to DB-9 Socket, 3 m	61-000165-02
QX Cordset, Host, Ethernet, M12 8-pin Plug (Screw-On) to RJ45, 1 m	61-000160-03
QX Cordset, M12 12-pin Plug to M12 12-pin Socket to DB-25 Plug Turck Connectors	61-000172-02
QX Cordset, M12 12-pin Plug & M12 12-pin Socket to MS-Connect 210, RS-232, 2 m	61-000158-03
QX Cordset, M12 12-pin Plug (Screw-On) to Flying Leads, 3 m	61-000166-02
QX Cordset, M12 12-pin Plug & Socket to IB-131, RS-232, 2 m	61-000159-03
QX Cordset, M12 12-pin Socket to IB-131, RS-232 / RS-485, 2 m	61-000159-04
Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01

Power Supplies

• •	
Туре	Model
Power Supply, 100-240 VAC, +24 VDC, M12 12-pin Socket	97-000012-01
Power Supply, 100-240 VAC, +24 VDC, M12 12-Pin Plug	97-000012-04

Note: Do not use the power supplies or power supply cords indicated in this catalog with any other electric or electronic equipment. When using the QX-870 Series, please use the power supply and power supply cord indicated in this catalog.

Mounting and Connectors

mountaing and connectors		
Туре	Model	
Mounting Plate Kit for QX-830 / QX-870	98-500006-01	
Right Angle Mirror Kit for QX-830	98-200026-02	
Mounting Arm / Adapter Kit for QX-830 / QX-870, 152 mm (6 inches)	98-000016-01	
Mounting Arm Extension Kit for all code readers,152 mm (6 inches)	98-000037-01	
L-Bracket Kit for QX Series	98-000148-01	
Mounting Stand Base Plate Kit	98-000054-01	
Trigger Connector, 4-pin Plug (screw terminal and field wireable for custom wiring into IB-131)	20-610024-01	

Ratings and Specifications

Applicable codes	Standard	Code 39, Codabar, Code 93, Interleaved 2 of 5, Code 128, PDF417, Micro PDF417, Pharmacode, UPC, GS1 Databar
	Application standards	UCC / EAN-128, AIAG
	Mirror type	Rotating, 10-faceted
	Scan rate	Adjustable from 300 to 1,400 scans/s, default=500
Reading	Scan width angle	60° (typ.)
performance	Pitch	±50° max.
	Skew	±40° max.
	Label contrast	25% min. absolute dark to light differential at 655 nm wavelength
	Interface	RS-232 / 422 / 485 and / or Ethernet*
Communications	Protocols	Point-to-Point, Point-to-Point w / RTS / CTS, Point-to-Point w / XON / XOFF, Point-to-Point w / RTS / CTS & XON / XOFF, Multidrop, Daisy Chain, User-Defined Multidrop, Ethernet TCP / IP, EtherNet / IP
1/0	Input 1 / Trigger / New Master	Bi-directional optoisolated 4.5 to 28 V rated (13 mA at 24 VDC)
I / O specifications	Outputs (1, 2 & 3)	Optoisolated, 1 to 28 V rated, (Ice <100 mA at 24 VDC, current limited by user)
Power requirement		10 to 28 VDC, 200 mV p-p max. ripple, 270 mA at 24 VDC (typ.)
	Туре	Laser diode
	Output wavelength	655 nm nominal
	Beam divergence	0.4 mrad (typ.)
Laser light	Pulse time	40 to 186 μs
	Maximum output	1.75 mW
	Operating life	50,000 hours at 25°C
	Safety class	Visible laser: IEC 60825-1 Class 2
	Ambient temperature range	Operating: 0 to 50°C, Storage: -40 to 75°C
Environmental specifications	Ambient humidity range	Up to 90% (with no icing or condensation)
specifications	Degree of protection	IP65
Weight		Approx. 453 g
Dimensions		109 x 45 x 95 mm (H x D x W)
Safety standards		FCC, UL/c UL, CE, CB, KC, RCM, EAC, BIS
Material		Aluminum diecast

^{*} Depends on model. See Ordering Information for details.

Raster Mirror Performance

Raster sweep angle	Maximum sweeps per second
1 to 10°	80
11 to 20°	60
21 to 34° (max.)	40
35 to 36° (max.)	20

PIN ASSIGNMENTS*

Connector A (Serial) M12 12-pin plug

Pir	Assignment
1	Trigger

1	Trigger
2	Power
3	Default
4	New Master
5	Output 1
6	Output 3
7	Ground
8	Input Common
9	Host RxD
10	Host TxD
11	Output 2
12	Output Common

Connector B (Serial) M12 12-pin socket

Pin Assignment

1	Trigger
2	Power
3	Terminated
4	Input 1
5	422 / 485 TxD (+)
6	422 / 485 RxD (+)
7	Ground
8	Input Common
9	TD / DTC
19	TxD / RTS
ř.	RxD / CTS
10	

M12 12-pin plug

Pin Assignment

	Assignment
1	N/C
2	Power
3	N/C
4	N/C
5	422 / 485 TxD (+)
6	422 / 485 RxD (+)
7	Ground
8	N/C
9	N/C
10	N/C
11	422 / 485 TxD (-)
12	422 / 485 RxD (-)

Connector P / M (Serial) Connector B (Ethernet) M12 8-pin socket

Pin Assignment


1	Terminated
2	Terminated
3	Terminated
4	TX (-)
5	RX (+)
6	TX (+)
7	Terminated
8	RX (-)


Connector T (Trigger) M12 4-pin socket


PII	n Assignment
1	Power
2	Trigger
3	Ground
4	Input

^{*}Note: Detailed connector pinout information is available in the User's Manual.

Read Ranges* (Unit: mm)









Narrow-bar-width	Read range
0.191 mm	254 to 305 mm
0.254 mm	178 to 381 mm
0.381 mm	152 to 483 mm
0.508 mm	127 to 558 mm
1.02 mm	102 to 762 mm

Narrow-bar-width	Read range
0.191 mm	64 to 140 mm
0.254 mm	38 to 178 mm
0.381 mm	38 to 216 mm
0.508 mm	38 to 280 mm
0.762 mm	25 to 304 mm

Narrow-bar-width	Read range
0.084 mm	Contact OMRON.
0.127 mm	102 to 127 mm
0.191 mm	89 to 171 mm
0.254 mm	82 to 203 mm
0.381 mm	82 to 228 mm

Dimensions (Unit: mm)






Laser Label Indications

This warning label is attached to the laser barcode reader. Never remove this label or place objects in front of it.


^{*} Ranges based on a Grade A, Code 39 label, at 500 scans per second. Data subject to change.

System Configurations

Stand Alone Configurations




Important: Ethernet or Serial connectivity is reader dependent See FISes for the appropriate reader model.



No.	Туре	Model
1	QX-870 Laser Barcode Reader	FIS-0870-□□□□G
2	QX Cordset, Host, Serial, M12 12-Pin Plug (Screw-On)-to-DB-9 Socket, 1 m.	61-000152-02 ^{*1}
3	Power Supply, 100-240VAC, +24VDC, M12 12-Pin Socket	97-000012-01
4	QX Cordset, Host, Ethernet, M8 8-Pin Plug (Screw-On)-to-RJ45, 1 m.	61-000160-03 ^{*1}
5	QX Cordset, M12 12-Pin Plug & M12 12-Pin Socket-to-MS-Connect 210 (RS-232), 2 m.	61-000158-03
6	Power Supply, 100-240VAC, +24VDC, TRK 3-Pin, U.S. / Euro Plug)	97-000012-02
7	Connectivity Box	FIS-0210-0001G*2
8	Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01
-	Kit, 6 in. Mounting Arm / Adapter, QX-830, QX-870	98-000016-01
-	Kit, Mounting Stand Base Plate	98-000054-01

Daisy Chain Configurations



No.	Туре	Model
1	QX-870 Laser Barcode Reader	FIS-0870-□□□□G
2	QX Cordset, Common, M12 12-Pin Socket (Screw-On)-to-M12 12-Pin Plug (Screw-On),1 m.	61-000162-02*
3	QX Cordset, Host, Serial, M12 12-Pin Plug (Screw-On)-to-DB-9 Socket, 1 m.	61-000152-02*
4	Power Supply, 100-240VAC, +24VDC, M12 12-Pin Socket	97-000012-01
5	QX Cordset, Host, Ethernet, M8 8-Pin Plug (Screw-On)-to-RJ45, 1 m.	61-000160-03 [*]
6	Photoelectric Sensor, M12, 4-pin Plug, NPN output, Cable length 2m	99-9000016-01
-	Kit, 6 in. Mounting Arm / Adapter, QX-830, QX-870	98-000016-01
-	Kit, Mounting Stand Base Plate	98-000054-01

^{*} Cordsets available in multiple lengths

^{*1.} Cordsets available in multiple lengths
*2. Refer to MS-Connection page for complete listing of MS-Connection 210 options

MEMO	
WEWO	
	_
	Laser Barcode Reader
	de R
	Barco
	aser E
	Ĭ
	ader
	Handleld Code Reader
	Cod
	ndlek
	Ŧ
	er
	Reac
	Multi Code Reader
	Aulti O
	2
	stem
	n Sy:
	icatio
	Code Verification System
	Code

Handheld DPM Code Reader

HS-360X series

"Ultra-Rugged" Hand Held Code Reader



The HS-360X Ultra-Rugged Handheld Code Reader is Omron Microscan's newest generation of industrial Direct Part Mark (DPM) handheld code reader, purpose built from the ground up to set new standards for durability and performance. With best in class out of box performance most applications require NO setup. An all NEW user interface WebLinkPc makes setup for more difficult applications intuitive and easy.

HS-360X:At a Glance

- Wired or Wireless
- Ultra-Rugged DPM Handheld Code Reader
- Industry-Leading DPM Decoding Performance with X-Mode
- Intuitive WebLink_{PC} Interface

HS-360X: Available Codes

Liner



Stacked

GS1 Databar

Matrix

PDF417

Micro OR 郻

2D

Please see the Ratings and Specifications for a complete list of supported symbologies.

Ultra-Rugged

The HS-360X withstands multiple drops from 8' and 5,000 tumbles.

X-Mode Decode Algorithms

The HS-360X includes industry-leading X-Mode decoding algorithms to consistently read damaged, distorted or otherwise challenging directly marked codes at high decode rates.

Performance Indicators

In addition to a beeper, visual and vibrating indicators provide silent confirmation of successful reads for noisy or sensitive environments

Industrial Fluid and **Chemical Tolerable**

Many industrial fluids and chemicals deemed tolerable.

Charging Station

The charging station is IP65 and transmits and receives data over a Bluetooth class 1 or 2 out to 300 feet. It includes a Wi-Fi friendly mode and a paging button to locate a misplaced code reader.

Ease of Use - WebLink_{PC}

Code reader configuration and deployment with browser based user interface and device discovery.

Ordering Information

Туре	Applicable countries	Model
Handheld DPM Code Reader, Wired, HDS-3608		HDS-3608-0001
Handheld DPM Code Reader, Wireless, HDS-3678	Common (except for India / Korea)	HDS-3678-0001
Battery Spare for HS-360X Wireless Type	(exception mala, notea)	98-9000224-01
Handheld DPM Code Reader, Wired, HDS-3608 INDIA / KOREA		HDS-3608-0002 [*]
Handheld DPM Code Reader, Wireless, HDS-3678 INDIA / KOREA	India / Korea	HDS-3678-0002 [*]
Battery Spare for HS-360X Wireless Type, INDIA / KOREA		98-9000224-02 [*]
Cradle / Charger, HS-360X Wireless Type		12-9000937-01
Cable, USB, Shielded, 2m (Power Supply Required)		12-9000942-01
Cable, USB, Shielded, 4.6m (Power Supply Required)	Common	12-9000943-01
Cable, USB, Shielded, 2m	Common	12-9000946-01
Cable, USB, Shielded, 4.6m		12-9000947-01
Cable, RS-232, DB9 Socket, 2M, Straight, HS-360X (Power Supply Required)		12-9000953-01
AC power Cord, 1.8m, JAPAN, C13 connector	Japan	12-9001046-01
AC power Cord, 1.9m, INDIA, C13 connector	India	12-9000963-01*
AC power Cord, 2.5m, US, C13 connector	United States	12-9000959-01
AC power Cord, 2.5m, EU / Korea, C13 connector	Europe / Korea	12-9000960-01
AC power Cord, 2.5m, UK, C13 connector	UK	12-9000961-01
AC power Cord, 2.5m, CHINA, C13 connector	China	12-9000962-01
KIT, Power Supply for Cradle / Charger, HS-360X Wireless Type (A / C Power Cord Required)		98-9000181-01
KIT, Power Supply for Battery Charger, 4 Slot, HS-360X Wireless Type (A / C Power Cord Required)	Common	98-9000182-01
4 Slot, Battery Charger, HS-360X Wireless Type (Power Supply Required)	Common	98-9000185-01
Intelligent Stand		98-9000186-01

Note: Do not use the power supplies or power supply cords indicated in this catalog with any other electric or electronic equipment. When using the HS-360X Series, please use the power supply and power supply cord indicated in this catalog.

^{*} These models are coming soon. Ask your Omron representative for more information.

Ratings and Specifications

	1D	UPC / EAN, UPC / EAN with supplementals, Bookland, EAN, ISSN, UCC Coupon Extended Code, Code 128, GS1-128, ISBT 128, ISBT Concatenation, Code 39, Code 39 Full ASCII, Trioptic Code 39, Code 32, Code 93, Code 11, Interleaved 2 of 5, Discrete 2 of 5, Codabar, MSI, Chinese 2 of 5, Matrix 2 of 5, Korean 3 of 5, GS1 DataBar variants	
Applicable codes	2D	PDF417, MicroPDF417, Composite Codes, TLC-39, Data Matrix, QR Code, MicroQR, Aztec, Han Xin, GS1-QR, GS1-DM	
	Postal	US Postnet, US Planet, UK Postal, Japan Post, Australia Post, Royal Mail 4 State Customer, UPU 4 State Postal FICS (Post US4), USPS 4 State Postal (Post US3)	
	Field of view (Horizontal x Vertical) nominal	31° (H) × 23° (V)	
	Roll	0 to 360°	
D !!	Pitch	±60°	
Reading performance	Skew	±60°	
	Scans per charge	Up to 100,000	
	Minimum resolution	Code 39: 0.0762 mm PDF417: 0.1016 mm DataMatrix: 0.1016 mm	
Interface		USB, RS-232 The code reader supports the following protocols over USB: HID Keyboard (default mode), SNAPI, COM Port Emulation, USB CDC	
Power		5 VDC + / - 10% @ 360 mA (RMS typical)	
Light source		Aiming pattern: Class 2 Laser 655nm Illumination: Exempt Risk Group, Warm white LED, Red 634nm LED	
Ambient temperature r		Wireless code reader Operating: -20 to +50°C, Storage: -40 to +70°C Wired code reader Operating: -30 to +50°C, Storage: -40 to +70°C	
Environmental	Ambient humidity range	5%RH to 95%RH (with no icing or condensation),	
specifications	Drop specifications	Withstands multiple 8 ft. / 2.4 m drops to concrete at room temperature.	
	Degree of protection	IP65 and IP67	
	ESD	20 kV air discharge: 10 kV contact discharge	
	Ambient light immunity	0 to 10,037 foot-candles / 0 to 108,000 Lux (direct sunlight)	
Weight		Wireless code reader: Approx. 402 g (with Battery) Wired code reader: Approx. 304 g (without Cable)	
Dimensions		Wireless code reader: 185 mm (H) \times 143 mm (D) \times 77 mm (W) Wired code reader: 185 mm (H) \times 132 mm (D) \times 77 mm (W)	

Cradle


Power requirements for host-powered	$5.0V\pm10\%$
Power requirements for external power supply	12.0V ± 5%
Typical current draw when not charging	80mA @ 5V; 30mA @ 12V
Typical current draw in safe charging mode	1200mA @ 5V (BC 1.2), 475mA (non-BC1.2); 700mA @ 12V
Typical current draw in safe charging mode	400mA @ 5V; 200mA @ 12V
Interfaces	USB, RS-232
Radio	Bluetooth, Up to 100 meters / 300 ft. in open air range / environment Serial Port & HID Profiles 2.402 to 2.480 GHz Adaptive Frequency Hopping (co-existence with 802.11 wireless networks) 3Mbit / s (2.1Mbit / s) for Classic Bluetooth 1Mbit / s (0.27Mbit / s) for Low Energy
Ambient temperature range	Operating: -20 to 50°C,Storage: -40 to 70°C
Charging temperature	0 to 40°C nominal, 5 to 35°C ideal
Ambient humidity range	5%RH to 95%RH (non-condensing)
ESD	25 kV air discharge 10 kV contact discharge
Weight	Approx. 390 g
Dimensions	82.6 mm (H) x 229.4 mm (D) x 99.8 mm (W)
Safety standards	UL / EN / IEC 60950-1 + AM2
EMC	IEC61000-4-(2,3,4,5,6,11)
EMI	FCC Part 15 Class B, ICES-003 Class B Japan VCCI Class B

Read Ranges (Unit: mm)

Parcodo Tuno	Symbol Density	HS-360X Typical Working Ranges	
Barcode Type		Near	Far
Code 39	0.0762 mm	5 mm	71 mm
PDF417	0.127 mm	5 mm	71 mm
PDF417	0.16764 mm	5 mm*	81 mm
DataMatrix	0.127 mm	10 mm	63 mm
DataMatrix	0.254 mm	0 mm	86 mm
QR Code	0.127 mm	10 mm	63 mm
Qn code	0.254 mm	0 mm	86 mm
UPC	0.3302 mm	25 mm*	147 mm

^{*} Field of view/barcode width limited. Decode ranges measured with Decoder Effort Level 1 (DPM Mode off), photographic paper barcodes, and under 30 fcd ambient light conditions.

Dimensions (Unit: mm)






Laser Label Indications

This warning label is attached to the code reader. Never remove this label or place objects in front of it.


System Configurations

Wired code reader (USB connection)



No.	Туре	Model
1	Handheld DPM Code Reader, Wired, HDS-3608	HDS-3608-0001
2	Cable, USB, Shielded, 2 m	12-9000946-01
3	Cable, USB, Shielded, 4.6 m	12-9000947-01


Wireless code reader (USB connection)



No.	Туре	Model
1	Handheld DPM Code Reader, Wireless, HDS-3678	HDS-3678-0001
2	Cable, USB, Shielded, 2 m *1 12-9000946-0	
3	Cable, USB, Shielded, 4.6 m *1	12-9000947-01
4	Cable, USB, Shielded, 2 m (power supply required) *1	12-9000942-01
5	Cable, USB, Shielded, 4.6 m (power supply required) *1	12-9000943-01
6	AC Power Cord, 1.8 m, JAPAN, C13 connector *2	12-9001046-01
7	KIT, Power Supply for Cradle/Charger, HS-360X Wireless Type (AC power cord required)	98-9000181-01
8	Cradle/Charger, HS-360X Wireless Type	12-9000937-01

- *1. Cables that require external power supply provide faster charge.
 From discharge to full charge: 10 hours max. using USB port only, 3 hours max. using external power supply
- *2. AC power cords that can be used in other countries are also available.


Wired code reader (RS-232 connection)



No.	Туре	Model
1	Handheld DPM Code Reader, Wired, HDS-3608	HDS-3608-0001
2	Cable, RS-232, DB9 Socket, 2 m, Straight, HS-360X (power supply required)	
3	KIT. Power Supply for Cradle/Charger, HS-360X	
4		

 $[\]ensuremath{^{*}}$ AC power cords that can be used in other countries are also available.

Wireless code reader (RS-232 connection)




No.	Туре	Model
1	Handheld DPM Code Reader, Wireless, HDS-3678 HDS-3678-00	
2	Cable, RS-232, DB9 Socket, 2 m, Straight, HS-360X (power supply required) 12-9000953-01	
3	AC Power Cord, 1.8 m, JAPAN, C13 connector * 12-9001046-01	
4	KIT, Power Supply for Cradle/Charger, HS-360X Wireless Type (AC power cord required) 98-9000181-01	
5	Cradle/Charger, HS-360X Wireless Type	12-9000937-01

^{*} AC power cords that can be used in other countries are also available.


System Configurations

Wireless code reader (Bluetooth connection)



No.	Туре	Model
1	Handheld DPM Code Reader, Wireless, HDS-3678	HDS-3678-0001

Charging spare batteries



No.	Туре	Model
1	Battery, Spare, HS-360X Wireless Type	98-9000224-01
2	4 Slots, Battery Charger, HS-360X Wireless Type (power supply required) 98-9000185-01	
3	KIT, Power Supply for Battery Charger, 4 Slots, HS-360X Wireless Type (AC power cord required) 98-9000182-01	
4	AC Power Cord, 1.8 m, JAPAN, C13 connector *	12-9001046-01

^{*} AC power cords that can be used in other countries are also available.

Auto Focus Multi Code Reader

V430-F series

Auto Focus Multi Code Reader



Powerful functionality in a compact design. The V430-F reliably reads different codes at different distances using the liquid lens.

V430-F: At a Glance

- Best in class: 5 Mpix *1
- Smallest in class *2
- Reading distance: 50 to 300 mm
- Maximum skew / pitch: 30°

V430-F: Available Codes

Linear



Stacked



GS1 Databar

2D Code

Data Matrix

Micro QR

Please see the Ratings and Specifications for a complete list of supported symbologies.

Refer to the V430 series catalog (Cat. No. Q258) for details.

Liquid lens for autofocus

The V430-F uses a liquid lens that does not need a drive mechanism or motor, providing unlimited autofocus and long life.

Quick troubleshooting from web browser

The V430-F has pre-installed software for setup. You can easily troubleshoot using a PC or tablet with the browser-based interface.

Print Quality Grading function

This function enables an in-line check of the relative quality change and the parameter where the change occurred.

Applicable standards

- ISO / IEC 15415
- ISO / IEC 15416
- ISO / IEC TR29158 (AMD PM-1-2006)
- ISO / IEC 16022

^{*1.} Fixed mount multi code reader. Based on Omron investigation in March 2018.

^{*2.} Fixed mount multi code readers with 1.2 Mpix or more.Based on Omron investigation in March 2018.

Auto Focus Multi Code Reader V430-F series

Ordering Information

Code Readers

Number of pixels	Field of view	Reading distance *	Model
E million nivels (Color)	Wide View	Autofocus	V430-F000W50C
5 million pixels (Color)	Middle View	50 to 300 mm	V430-F000M50C
1.2 million pixels	Wide View	Autofocus	V430-F000W12M
	Middle View	50 to 300 mm	V430-F000M12M
(Monochrome)	Narrow View	Autofocus 40 to 150 mm	V430-F000N12M
0.3 million pixels (Monochrome)		Fixed Focus 50 mm	V430-F050M03M
	Middle View	Fixed Focus 81 mm	V430-F081M03M
`		Fixed Focus 102 mm	V430-F102M03M

^{*} Refer to Read Ranges on p.31 for detail.

Mounting Brackets

Туре	Model
Angle adjustable Bracket (L Bracket)	V430-AM0
Mounting Block	V430-AM1
Isolation Mounting Kit	98-9000064-01

Cables (Bending Resistant Cables)

Туре	Connector	Length	Model
I/O Cable	Straight	3 m	V430-W8-3M
	Straight	5 m	V430-W8-5M
	Right angle down	3 m	V430-W8LD-3M
	Right angle up	3 m	V430-W8LU-3M
	Straight	3 m	V430-WE-3M
Ethernet Cable	Straight	5 m	V430-WE-5M
Ethernet Cable	Right angle down	3 m	V430-WELD-3M
	Right angle up	3 m	V430-WELU-3M
Cordset, M12 12-pin Socket to DB9 Socket with M12 12-pin Plug	Straight	3 m	V430-W2-3M

Optics Options


Туре	Model
Front Window (for replacement)	V430-AF0
Diffuser	V430-AF1
Polarizer	V430-AF2
Right Angle Mirror	V430-AF3

Auto Focus Multi Code Reader V430-F series

Ratings and Specifications

	Model	V430-F000□50C	V430-F000□12M	V430-F□□□M03M		
Applicable Bar code		Code 39, Code 128, BC412, ITF (Interleaved 2 of 5), EAN / UPC, Codabar, Code 93, Pharmacode, PLANET, POSTNET, Japanese Post, Australian Post, Royal Mail, Intelligent Mail, KIX, UPU, GS1 Databar (Composite)				
codes *1	2D code	DataMatrix (ECC000-ECC200), GS1 DataMatrix, QR Code, Micro QR Code, Aztec Code, DotCode, PDF417, Micro PDF417, GS1 Databar (Stacked)				
	Number of reading digits	No upper limit (depends on bar widt	h and reading distance)			
Aiming light		Two Blue LEDs				
		Inner LEDs: Four White and Four Red	LEDs (wave length: 625 nm)			
Reading	Light source	Outer LEDs: Eight White LEDs	Outer LEDs: Eight Red LEDs (wave length: 617 nm)	Outer LEDs: Eight Red LEDs (wave length: 617 nm)		
performance *2	Reading distance / Field of view	Refer to Read Ranges on page 31 for detail.				
	Pitch angle (α)	±30°				
	Skew angle (β)	±30°				
	Tilt angle (γ)	±180°				
	Effective pixels	2592 (H) x 1944 (V)	1280 (H) x 960 (V)	752 (H) x 480 (V)		
	Color / Monochrome	Color CMOS	Monochrome CMOS	Monochrome CMOS		
mage capture device	Shutter method	Rolling shutter	Global shutter	Global shutter		
acvice	Frame rate	5 fps	42 fps	60 fps		
	Shutter speed	50 us to 100 ms				
mage logging		FTP				
Reading trigger		External trigger (edge, level), Trigger by command (Ethernet, RS-232C)				
	Input signals	Trigger, New Master: 4.5 to 28 V rated (10 mA at 28 VDC)				
1/0	Output signals	Output1, Output2, Output3: 1 to 28 V rated (100 mA Max. at 24 VDC)				
specifications	Communication specification *4	RS-232C, Ethernet TCP / IP, EtherNet / IP™, PROFINET				
	Ethernet specifications	100BASE-TX / 10BASE-T				
Indicator lamps		PASS (Green), TRIG (Amber), MODE (A	Amber), LINK (Amber), FAIL (Red), PWI	R (Green)		
Power voltage		5.0 to 30.0 VDC (including ripple)				
Consumption cu	rrent	0.18 A (typ.) (at 24 VDC)				
	Ambient temperature range	Operating: 0 to 40°C, Storage: -50 to	+75°C (with no icing or condensation	1)		
	Ambient humidity range	Operating: 5 to 85%RH, Storage: 5 to 85%RH (with no condensation)				
Environmental	Ambient atmosphere	No corrosive gases				
specifications	Vibration resistance (destruction)	10 to 55 Hz, double amplitude: 0.35 mm, X / Y / Z directions, 10 cycles / axis				
	Shock resistance (destruction)	150 m / s², 3 times in each X / Y / Z directions				
	Degree of protection	IEC 60529 IP67				
Weight	Main body only	Approx. 68 g				
	Packing weight	Approx. 174 g (including packing)				
Dimensions Main body Dimension Packing Dimension		44.5 (W) × 44.5 (D) × 25.4 (H) mm				
		170 (W) × 117 (D) × 86 (H) mm				
Accessories		Instruction manual ("Read me first"), Compliance Sheet (CE)				
LED class		Risk Group Exempt (IEC 62471-1)				
Safety standards		EN61326-1: 2013 FCC Part 15, Subpart B (Class A) KC CISPR 11, IEC 61000-4-2: 2008 UL60950-1 RCM, EAC, BSMI, BIS				
Material Case Reading window		Aluminum diecast, alumite (black)				
		Acrylic				

^{*1.} These are the code types supported based on Omron's read capability validation standard. It is recommended that the customer do its own validation in its actual work environment.
*2. Unless otherwise specified, the reading performance is defined with center of field of view, angle R=∞.
*3. Pitch angle
Skew angle
Tilt angle



^{*4.} EtherNet/IP and PROFINET are supported in firmware version 1.3.1 and later.


Auto Focus Multi Code Reader V430-F series

Read Ranges (Reference)

		Reading distance	Field of view (mm)		Reading ranges (mm)		Minimum 2D cell size (Reference)	
		(mm)	Horizontal	Vertical	Inside	Outside	(mm)	
			50	51	37	43	59	0.09
		Wide View 430-F000W50C	102	96	75	80	124	-
5 million	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		300	265	210	203	397	-
pixels		Middle View 430-F000M50C	50	35.5	25	46.5	54.5	0.09
			102	66	49	94	110	-
	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	+30-1 0001V130C	300	184	143	227	373	-
		Wide View 430-F000W12M	50	57.2	42.9	37	64	0.13
	\/A		102	109.5	82.2	74	131	-
	V4		300	314.3	235.7	224	427	-
		Middle View 430-F000M12M	50	36.5	27.4	47.5	55	0.09
			102	71.4	53.6	88	116	-
pixeis			300	198.4	148.8	185	400	-
		Narrow View V430-F000N12M	40	10	7.5	38.5	41.5	0.05
V			81	20.6	15.4	78.5	83.5	-
	V430-F000IN [Z]VI		39	29.5	132	153	-	
		V430-F050M03M	50	35	21.5	43	58	0.13
0.3 million pixels	Middle View	Middle View V430-F081M03M	81	49	33	65	97	0.19
pixeis		V430-F102M03M	102	65	41	83	121	0.26

Dimensions (Unit: mm)

Code Reader V430-F



Related Manuals

Cat. No.	Model	Manual
Z392	V430	Auto Focus Multi Code Reader V430-F-series User's Manual

Handleld Code Reader

Code Verification System

LVS-9510 series

Desktop Barcode Verification System



Comes with handheld top cover (not shown) to keep label in position on viewing window.

LVS-9510: At a Glance

- Validates to ISO / IEC, ANSI, GS1, and UDI print quality standards.
- · Software upgrade options include Multi-Sector for verification of multiple barcodes on a label.
- 21 CFR Part 11 compliant-ready.
- · Certified by GS1 US.
- · Supports 15 languages.
- Quality data reporting for auditing purposes.
- Manage operator permissions using LVS-95XX software or using Microsoft Active Directory.
- Includes NIST-Traceable Calibrated Conformance Standard Test Card for calibrating the system.

LVS-9510: Available Symbologies

Linear Data Matrix

2D

燚

郻

Micro QR

Halalalllaalll

Postal

Aztec 県

Stacked



PDF417



Please see the Ratings and Specifications for a complete list of supported symbologies.

The LVS-9510 is a high-performance system for offline verification of barcodes to ISO / IEC, ANSI, GS1, and UDI standards.

The LVS-9510 is unique in the world of ISO verification due to its ease of use and ability to verify linear (1D) and two-dimensional (2D) codes without any change of equipment. The system automatically determines the symbology and aperture needed to evaluate the code and identifies and highlights trouble spots.

The LVS-9510 offers a "stitching" feature that allows grading of barcodes that are larger than the field of view.

ISO / ANSI for 1D

LVS-95XX series barcode verifiers inspect all nine ISO / ANSI parameters for linear (1D) barcodes, have the ability to identify blemishes, and can perform simple human-readable validation.

ISO / ANSI for 2D

The LVS-95XX series verifies 2D codes and reports all parameters as specified in the applicable symbology specification.

Analytical Tools

Equipped with numerous analytical tools to identify and evaluate barcode errors. Problems are color-coded to make problem solving easy.

Software

LVS-95XX software includes GS1 System Symbol Specification Tables. GS1 tables set standards for barcode data structure and how to maintain the quality of codes during barcode creation. **OMRON Microscan offers** an online training course on GS1 tables and how these apply to different organizations.

Software Upgrade: EAIV

The Enhanced Application Identifier Verification (EAIV) option verifies that all GS1 Application Identifiers, such as Expiration Date, Global Trade Item Number (GTIN), and Batch Number, embedded in the data structure of a GS1 barcode match the data pr grammed in the EAIV feature by the user.

User Permission Options

Manage permissions through LVS-95XX software: Passwords are stored in a local database. All passwords are encrypted, include an expiration date, and count failed password attempts.

Manage permissions through Microsoft Active Directory: User privileges are based on Microsoft authentication and LVS-95XX permissions are assigned based on group membership.

Handleld Code Reader

Code Verification System LVS-9510 series

Ordering Information

Code Verification Systems

Туре	Field of view	Model	
	76 mm	9510-5-3.0	
LVS-9510 Verifier	102 mm	9510-5-4.0	
LV3-93 TO Verifier	144 mm	9510-5-4.5	
	159 mm	9510-5-6.250	

Note: Be sure to use the power supply and power supply cord included with the product.

In addition, do not use the power supplies or power supply cords with any other electric or electronic equipment.

Accessories

Туре	Model
EAN / UPC Calibrated Conformance Test Card (Included with 9510-5-3.0 / 4.0 / 4.5 / 6 / 250)	98-CAL020
GS1-128 Calibrated Conformance Test Card (Included with 9510-5-6.250)	98-CAL021
Data Matrix Calibrated Conformance Test Card	98-CAL010
LVS-9510 and LVS-958□ Software Upgrade Option: Multi-Sector Verification	98-SOF0039
LVS-95 ☐ Software Upgrade Option: Automatic Login Feature	98-SOF0056
Software Upgrade Option: EAIV (Enhanced Application Identifier Verification)	98-SOF0088
LVS-95 IQ-OQ Validation Procedure Guidelines, v. 4.3 and later (includes text cards)	98-LVS0077
Validation Test Cards (25 test cards)	98-LVS-VTC

Code Verification System LVS-9510 series

Ratings and Specifications

		AIAG / DAMA / JAPIA / Odette
		ALDI
		ISO / IEC TR 29158 (DPM Cat 0)
		DHL
		FPMAJ
		French CIP GS1 General Specifications
		HDMA Guidelines
		Health Industry Barcode (HIBC)
		IFAH
		ISO / IEC 15415 / 15416
		Italian Pharmacode
		Japan Codabar
	Application standards	Laetus Miniature Pharmacode
	/ Apprication standards	Laetus Pharmacode
		Laetus Standard
		MIL-STD-130N Change 1 Pharmacy Product Number (PPN)
		Automatic GS1 or ISO
		Chinese Sensible (Han Xin) Code
		GS1 General Specifications
Supported standards		GS1 (NTIN)
		HDMA Guidelines
		Miniature Pharmacode
		Postal (EIB, USPS IMB / Code 128, POSTNET, Japan Post)
		PPN Code PZN big normal small (Corman Pharmacode)
		PZN-big, normal, small (German Pharmacode) PZN 7 and PZN 8
		Data Matrix for Healthcare
		Data Matrix (ECC 200)
		EAN/UPC
		EAN / UPC and extended codes
		EAN / UPC with CC
	GS1 US certification	GS1 DataBar Omnidirectional
		ITF-14
		GS1 DataBar-14 with CC (formerly RSS-14 with CC)
		UCC / EAN with Supplementals UCC / EAN-128
		UCC / EAN-128 with CC
		ISO / IEC 15415, 15416, 15418
		ISO / IEC 15426-1, 15426-2
	ISO conformance standards	ISO / IEC TR29158 (DPM Cat 0) / AIM DPM-1-2006
		All supported ISO / IEC symbology specifications
		Codabar
		Code 128, Code 39, Code 93
		GS1 DataBar Expanded and Limited DataBar
		DataBar Expanded and Limited
		DataBar Omnidirectional
		DataBar Stacked and Truncated
		EAN / JAN-13
		EAN / JAN-8
	Linear (1D) symbologies	Enterprise Intelligent Barcode (EIB) 4-State (4SB)
		GS1-128 Hanxin Code
		HIBC
		Interleaved 2 of 5 (ITF)
		ITF-14
		Japan Post
		MSI Plessey
		Pharmacode–Italian and Laetus
Supported symbologies		PZN 7, PZN 8
Supported symbologies		UPC-A, UPC-E USPS-128
		USPS Intelligent Mail Barcode (4-State Customer Barcode)
	Two-dimensional (2D) symbologies	Aztec
		DataBar with CC-A, CC-B, or CC-C
		EAN / JAN-13 with CC-A, CC-B, or CC-C
		EAN / JAN-8 with CC-A, CC-B, or CC-C
		ECC-200 (Data Matrix)
		• EIB CMDM • French CIP
		• GS1 Data Matrix
		• NTIN and PPN
		GS1-128 with CC-A, CC-B, or CC-C
		MaxiCode
		Micro QR Code
		MicroPDF417
		PDF417 QR Code
		UPC-A with CC-A, CC-B, or CC-C
		UPC-E with CC-A, CC-B, or CC-C
		and a complete of the contract

^{*} Contact OMRON for a complete list of supported ECC-200 (Data Matrix) codes.

Code Verification System LVS-9510 series


		• Windows® 7 Professional, Windows® 8.1 Pro, or Windows® 10 Pro
		• Intel® Core™ 2 Duo Processor or higher
Minimum PC requirements (PC supplied by customer)		• 2 GB RAM
		• 800 x 600 screen resolution
		One USB 2.0 port available per unit
Camera		Monochrome 5 million pixels
Illumination		White LED, red filter (660 nm)
Environmental	Ambient temperature range	Operating: 10 to 30°C, Storage: 0 to 40°C
specifications	Ambient humidity range	Operating: 20% to 80% (with no icing or condensation),
specifications	Ambient numicity range	Storage: 20% to 95% (with no icing or condensation)
Communications		USB 2.0 A plug to B plug cable, 1.8 m
Power voltage		12 VDC at 2.5 A max.
	Unpackaged standalone	Approx. 2.72 kg
Weight	Shipping weight	Approx. 5.89 kg
		(Includes all items packaged in shipping box, such as power supply and cables)
Dimensions		279.4 x 228.6 x 279.4 mm (H x D x W) (Includes rubber feet on system base)
Ton cover	Dimensions	139.7 x 190.5 mm
Top cover	Weight	Approx. 155.92 g
Safety standards		FCC, CE, UL
		Included with 9510-5-3.0: EAN / UPC Calibrated Conformance Standard Test Card
Calibrated Conformance Test Card (Included with system)		• Included with 9510-5-4.0: EAN / UPC Calibrated Conformance Standard Test Card
		Included with 9510-5-4.5: EAN / UPC Calibrated Conformance Standard Test Card
		• Included with 9510-5-6.250: GS1-128 Calibrated Conformance Standard Test Card
Calibrated Conformance Test Card (Option)		• EAN / UPC Calibrated Conformance Standard Test Card (Model: 98-CAL020)
		GS1-128 Calibrated Conformance Standard Test Card (Model: 98-CAL021)

Options

Field of View Options

Model	Minimum X dimension (nominal)		Field of view
	1D	2D	(approximate)
9510-5-3.0	0.10 mm	0.15 mm	76 mm
9510-5-4.0	0.15 mm	0.23 mm	102 mm
9510-5-4.5	0.18 mm	0.25 mm	144 mm
9510-5-6.250	0.24 mm	0.33 mm	159 mm

Dimensions (Unit: mm)



Code Verification System

LVS-9585 series

Portable Barcode Verification System



LVS-9585: At a Glance

- Verify a broad variety of direct part marks as well as 1D and 2D printed barcodes with a single model.
- Software automatically selects best lighting performance from integrated red or white dome and 30° angle lighting.
- Validates printed barcodes to ISO / IEC, ANSI, GS1, and UDI print quality standards.
- \bullet Validates direct part marks (DPM) to ISO, MIL-STD-130, and GS1 standards.
- Software options include Multi-Sector for verification of multiple barcodes and GS1 Al content check.
- 21 CFR Part 11 compliant-ready.
- · Supports 15 languages.
- Export verification reports to Excel or SQL database.
- Includes NIST-Traceable Calibrated Conformance Standard Test Card for calibrating the system.

LVS-9585: Available Symbologies

Linear

Data Matrix
QR
Micro QR
Aztec

Micro PDF
PDF417

Stacked

Please see Ratings and Specifications for a

complete list of supported symbologies.

The LVS-9585 is a high-performance handheld solution for off-line barcode verification to ISO / IEC, ANSI, and GS1 standards. Featuring a high-resolution 5.0 megapixel camera, the LVS-9585 reads and analyzes linear (1D) and two-dimensional (2D) codes up to 76.19 mm wide and up to 57.15 mm tall. 1D and 2D direct part marks (DPM) of up to 44 mm x 44 mm can be verified to MIL-STD-130, ISO, and GS1 standards.

The LVS-9585 verifies multiple symbologies, including any combination of linear, 2D (Data Matrix, QR Code, and Aztec Code), and stacked linear (PDF417, MicroPDF, and Composite codes).

Powered by a 2.0 m USB 2.0 cable, the LVS-9585 verifies barcodes on a wide range of surfaces including plastics, PCBs, metal, cardboard, and shipping containers.

ISO/ANSI for 1D

LVS-95XX series barcode verifiers inspect all nine ISO and ANSI parameters for linear (1D) barcodes, have the ability to identify blemishes, and can perform simple human-readable validation.

ISO/ANSI for 2D

The LVS-95XX series verifies 2D codes and reports all parameters as specified in the applicable symbology specification.

Analytical Tools

Equipped with numerous analytical tools to identify and evaluate barcode errors. Problems are color-coded to make problem solving easy.

Software

LVS-95XX software includes GS1 System Symbol Specification Tables. GS1 tables set standards for barcode data structure and how to maintain the quality of codes during barcode creation. OMRON Microscan offers an onlinetraining course on GS1 tables and how these apply to different organizations.

Software Upgrade: EAIV

The Enhanced Application Identifier Verification (EAIV) option verifies that all GS1 Application Identifiers, such as Expiration Date, Global Trade Item Number (GTIN), and Batch Number, embedded in the datastructure of a GS1 barcode match the data programmed in the EAIV feature by the user.

User Permission Options

Manage permissions through LVS-95XX software: Passwords are stored in a local database. All passwords are encrypted, include an expiration date, and count failed password attempts.

Manage permission through Microsoft Active Directory: User privileges are based on Microsoft authentication and LVS-95XX permissions are assigned based on group membership.

Portability

Connects to the latest Windows OS tablets.

Handleld Code Reader

Code Verification System LVS-9585 series

Ordering Information

Code Verification Systems

Туре	Model
LVS-9585 Handheld 1D, 2D & DPM Barcode Verification, High Resolution	9585-DPM-HD
LVS-9585 Handheld 1D, 2D & DPM Barcode Verification, Red and White Light	9585-DPM

Accessories

Туре	Model
EAN / UPC Calibrated Conformance Test Card	98-CAL020
GS1-128 Calibrated Conformance Test Card	98-CAL021
Data Matrix Calibrated Conformance Standard Test Card (for 9585-DPM)	98-CAL010
Data Matrix Calibrated Conformance Standard Test Card (for 9585-DPM-HD)	98-CAL022
LVS-9510 and LVS-958□ Software Upgrade Option: Multi-Sector Verification	98-SOF0039
LVS-95□□ Software Upgrade Option: Automatic Login Feature	98-SOF0056
Software Upgrade Option: EAIV (Enhanced Application Identifier Verification)	98-SOF0088
LVS-9580 Upgrade (1D / 2D to DPM)	98-SOF0095
LVS-95□□ IQ-OQ Validation Procedure Guidelines, v. 4.3 and later (includes text cards)	98-LVS0077
Validation Test Cards (25 test cards)	98-LVS-VTC

Code Verification System LVS-9585 series

Ratings and Specifications


		AIAG / DAMA / JAPIA / Odette
		ALDI
		ISO / IEC TR 29158
		DHL
		FPMAJ
		French CIP
		GS1 General Specifications
		HDMA Guidelines
		Health Industry Barcode (HIBC)
		IFAH
		ISO / IEC 15415 / 15416
	Application standards	Italian Pharmacode
		Japan Codabar
		Laetus Miniature Pharmacode
		Laetus Pharmacode
		Laetus Standard
		MIL-STD-130N Change 1
		Pharmacy Product Number (PPN)
		Automatic GS1 or ISO
Supported standards		GS1 (NTIN)
		Miniature Pharmacode
		Postal (EIB, USPS IMB / Code 128, POSTNET, Japan Post)
		PZN-big, normal, small (German Pharmacode)
		Data Matrix for Healthcare
		Data Matrix (ECC 200)
		EAN / UPC
		EAN / UPC and Extended Codes
		EAN / UPC with CC
	GS1 US certification	GS1 DataBar Omnidirectional
	d31 03 certification	TF-14
		GS1 DataBar-14 with CC (formerly RSS-14 with CC)
		UCC / EAN with Supplementals
		UCC / EAN With Supplementals
		UCC / EAN-128 with CC
		ISO / IEC 15415, 15416, 15418
	ISO conformance standards	ISO / IEC 15426-1, 15426-2
		ISO / IEC TR29158(DPM Cat 0, 1, 2) / AIM DPM-1-2006
		All supported ISO / IEC symbology specifications
		Codabar Coda 120 Coda 20 Coda
		Code 128, Code 39, Code 93
		GS1 DataBar Expanded and Limited
		DataBar Data Bar San and a state of the stat
		DataBar Expanded and Limited
		DataBar Omnidirectional
		DataBar Stacked and Truncated
		EAN / JAN-13
		EAN / JAN-8
		Enterprise Intelligent Barcode (EIB) 4-State (4SB)
		French CIP
	Linear (1D) symbologies	GS1-128
	Linear (1D) symbologies	GS1-128 Hanxin Code
	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC
	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF)
	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14
	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post
	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode–Italian and Laetus
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode–Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode—Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode)
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode—Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode–Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C
Supported symbologies	Linear (1D) symbologies	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode—Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix)
Supported symbologies		GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode–Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM)
Supported symbologies	Two-dimensional (2D)	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM) GS1-128 with CC-A, CC-B, or CC-C
Supported symbologies		GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM) GS1-128 with CC-A, CC-B, or CC-C Micro QR Code
Supported symbologies	Two-dimensional (2D)	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM) GS1-128 with CC-A, CC-B, or CC-C
Supported symbologies	Two-dimensional (2D)	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM) GS1-128 with CC-A, CC-B, or CC-C Micro QR Code
Supported symbologies	Two-dimensional (2D)	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM) GS1-128 with CC-A, CC-B, or CC-C Micro QR Code MicroPDF417
Supported symbologies	Two-dimensional (2D)	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode-Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM) GS1-128 with CC-A, CC-B, or CC-C Micro QR Code MicroPDF417 PDF417
Supported symbologies	Two-dimensional (2D)	GS1-128 Hanxin Code HIBC Interleaved 2 of 5 (ITF) ITF-14 Japan Post MaxiCode MSI Plessey Pharmacode–Italian and Laetus PZN 7 and PZN 8 UPC-A and UPC-E USPS-128 USPS Intelligent Mail Barcode (4-State Barcode) Aztec Code DataBar with CC-A, CC-B, or CC-C EAN / JAN-13 with CC-A, CC-B, or CC-C EAN / JAN-8 with CC-A, CC-B, or CC-C ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM) GS1-128 with CC-A, CC-B, or CC-C Micro QR Code MicroPDF417 PDF417 QR Code

 $[\]mbox{\ensuremath{^{*}}}$ Contact OMRON for a complete list of supported ECC-200 (Data Matrix) codes. CC=Composite Components

Code Verification System LVS-9585 series

		• Windows®7 Pro SP1 or Windows®10 Pro
		• Intel® Core™ i3 or higher
Minimum PC requirements (PC supplied by customer)		• 4 GB RAM
		• 800 x 600 screen resolution;
		One USB 2.0 port available per unit
Field of view	DPM (9585-DPM)	44 x 44 mm
rieid of view	HD (9585-DPM-HD)	33 x 30 mm
	DPM (9585-DPM)	1D = 4.0 mils (0.10 mm)
Minimum cell size	DPW (9383-DPW)	2D = 5.9 mils (0.15 mm)
	HD (9585-DPM-HD)	2D = 2.0 mils (0.05 mm)
Camera		5 million pixels
Camera		Object distance: Contact
Illumination		Red dome (660 nm), white dome, 30° angle
Environmental	Ambient temperature range	Operating: 4 to 46°C, Storage: -20 to 60°C
specifications	Ambient humiditurenge	Operating: 20% to 80% (with no icing or condensation),
specifications	Ambient humidity range	Storage: 20% to 95% (with no icing or condensation)
Communications		USB 2.0 A plug to Mini-B plug cable, 2 m
Power supply		USB powered 5 VDC at 400 mA
Maiaht	Unpackaged standalone	Approx. 0.68 kg
Weight	Shipping weight	Approx. 1.51 kg (Includes all cables and other items packaged in shipping box)
Dimensions		215.9 x 139.7 x 120.6 mm (H x D x W)
Calibrated Conformand	ce Test Card	Included with 9585-DPM: EAN / UPC Calibrated Conformance Standard Test Card
(Included with system)		Included with 9585-DPM-HD: Data Matrix Calibrated Conformance Standard Test Card
Safety standards		FCC, CE, UL

Dimensions (Unit: mm)



Handleld Code Reader

Code Verification System

LVS-9580 series

Portable Barcode **Verification System**



LVS-9580: At a Glance

- · Stitching feature to grade barcodes larger than the field of view.
- Ideal for multiple line production and warehouse environments.
- · Validates printed barcodes to ISO / IEC, ANSI, GS1, and UDI print quality standards.
- · Validates direct part marks (DPM) to ISO, MIL-STD-130, and GS1 standards.
- Software upgrade options include Multi-Sector for verification of multiple barcodes on a label.
- 21 CFR Part 11 compliant-ready.
- · Supports 15 languages.
- · Quality data reporting for auditing purposes.
- Includes NIST-Traceable Calibrated Conformance Standard Test Card for calibrating the system.

LVS-9580: Available Symbologies

Linear

11..1..1..111.....1.111

2D









Stacked







Please see the Ratings and Specifications for a complete list of supported symbologies.

The LVS-9580 is a high-performance handheld solution for off-line barcode verification to ISO / IEC, ANSI, GS1, and UDI standards. Featuring a highresolution 5.0 megapixel camera, the LVS-9580 reads and analyzes linear (1D) and two-dimensional (2D) codes up to 76.19 mm wide and up to 57.15 mm tall. 1D and 2D direct part marks (DPM) of up to 44 mm x 44 mm can be verified to MIL-STD-130, ISO, and GS1 standards.

The LVS-9580 verifies multiple symbologies, including any combination of linear, 2D (Data Matrix, QR Code, and Aztec Code), and stacked linear (PDF417, MicroPDF, and Composite codes).

Powered by a 2.0 m USB 2.0 cable, the LVS-9580 verifies barcodes on a wide range of surfaces including plastics, PCBs, metal, cardboard, and shipping containers.

ISO/ANSI for 1D

LVS-95XX series barcode verifiers inspect all nine ISO and ANSI parameters for linear (1D) barcodes, have the ability to identify blemishes, and can perform simple human-readable validation.

ISO/ANSI for 2D

The LVS-95XX series verifies 2D codes and reports all parameters as specified in the applicable symbology specification.

Analytical Tools

Equipped with numerous analytical tools to identify and evaluate barcode errors. Problems are color-coded to make problem solving easy.

Software

LVS-95XX software includes GS1 System Symbol Specification Tables. GS1 tables set standards for barcode data structure and how to maintain the quality of codes during barcode creation. OMRON Microscan offers an online training course on GS1 tables and how these apply to different organizations.

Software Upgrade: EAIV

The Enhanced Application Identifier Verification (EAIV) option verifies that all GS1 Application Identifiers, such as Expiration Date, Global Trade Item Number (GTIN), and Batch Number, embedded in the data structure of a GS1 barcode match the data programmed in the EAIV feature by the user.

User Permission Options

Manage permissions through LVS-95XX software: Passwords are stored in a local database. All passwords are encrypted, include an expiration date, and count failed password attempts.

Manage permissions through Microsoft Active Directory: User privileges are based on Microsoft authentication and LVS-95XX permissions are assigned based on group membership.

Portability

Connects to the latest Windows OS tablets.

Code Verification System LVS-9580 series

Ordering Information

Code Verification Systems

Туре	Model
LVS-9580 Handheld 1D & 2D Barcode Verification	9580-C-3
LVS-9580 Handheld 1D, 2D & DPM Barcode Verification	9580-DPM
LVS-9580 Handheld 1D, 2D & DPM Barcode Verification, High Resolution	9580-DPM-HD

Accessories

Туре	Model
EAN / UPC Calibrated Conformance Test Card	98-CAL020
GS1-128 Calibrated Conformance Test Card	98-CAL021
Data Matrix Calibrated Conformance Standard Test Card (for 9580-C-3 / 9580-DPM)	98-CAL010
Data Matrix Calibrated Conformance Standard Test Card (for 9580-DPM-HD)	98-CAL022
LVS-9510 and LVS-958□ Software Upgrade Option: Multi-Sector Verification	98-SOF0039
LVS-95□□ Software Upgrade Option: Automatic Login Feature	98-SOF0056
Software Upgrade Option: EAIV (Enhanced Application Identifier Verification)	98-SOF0088
LVS-9580 Upgrade (1D / 2D to DPM)	98-SOF0095
LVS-95 ☐ IQ-OQ Validation Procedure Guidelines, v. 4.3 and later (includes text cards)	98-LVS0077
Validation Test Cards (25 test cards)	98-LVS-VTC

Ratings and Specifications


		AIAG / DAMA / JAPIA / Odette
		ALDI
		ISO / IEC TR 29158
		DHL.
		FPMAJ
		French CIP
		GS1 General Specifications
		HDMA Guidelines
		Health Industry Barcode (HIBC)
		IFAH
		ISO / IEC 15415 / 15416
	Application standards	Italian Pharmacode
	1.166	Japan Codabar
		Laetus Miniature Pharmacode
		Laetus Pharmacode
		Laetus Standard
		MIL-STD-130N Change 1
		Pharmacy Product Number (PPN)
		Automatic GS1 or ISO
Supported standards		GS1 (NTIN)
		Miniature Pharmacode
		Postal (EIB, USPS IMB / Code 128, POSTNET, Japan Post)
		PZN-big normal small (German Pharmacode)
	GS1 (NTIN)	Data Matrix for Healthcare
		Data Matrix (ECC 200)
		EAN / UPC
		EAN / UPC and Extended Codes
		EAN / UPC with CC
		GS1 DataBar Omnidirectional
		ITF-14
		GS1 DataBar-14 with CC (formerly RSS-14 with CC)
		UCC / EAN with Supplementals
		UCC / EAN-128
		UCC / EAN-128 with CC
	ISO conformance standards	ISO / IEC 15415, 15416, 15418
		ISO / IEC 15426-1, 15426-2
		ISO / IEC TR29158 (DPM Cat 0) / AIM DPM-1-2006
		All supported ISO/IEC symbology specifications

Code Verification System LVS-9580 series

		Codabar Coda 139 Coda 30 Coda 03
		Code 128 Code 39 Code 93 GS1 DataBar Expanded and Limited
		DataBar
		DataBar Expanded and Limited
		DataBar Omnidirectional
		DataBar Stacked and Truncated
		EAN / JAN-13
		EAN / JAN-8 Enterprise Intelligent Paycode (EID) 4 State (4SP)
		Enterprise Intelligent Barcode (EIB) 4-State (4SB) French CIP
		GS1-128
	Linear (1D) symbologies	Hanxin Code
		HIBC
		Interleaved 2 of 5 (ITF)
		ITF-14 Japan Post
		MaxiCode
Supported symbologies		MSI Plessey
		Pharmacode–Italian and Laetus
		PZN 7 and PZN 8
		UPC-A and UPC-E USPS-128
		USPS Intelligent Mail Barcode (4-State Barcode)
		Aztec Code
		DataBar with CC-A, CC-B, or CC-C
		EAN / JAN-13 with CC-A, CC-B, or CC-C
		EAN / JAN-8 with CC-A, CC-B, or CC-C
		ECC-200 (Data Matrix) Enterprise Intelligent Barcode (EIB) Complex Mail Data Marks (CMDM)
	Two-dimensional (2D)	GS1-128 with CC-A, CC-B, or CC-C
	symbologies	Micro QR Code
		MicroPDF417
		PDF417
		QR Code UPC-A with CC-A, CC-B, or CC-C
		UPC-E with CC-A, CC-B, or CC-C
	-	• Windows®7 Pro SP1 or Windows®10 Pro
		• Intel® Core™ i3 or higher
Minimum PC requirements	(PC supplied by customer)	• 4 GB RAM
		• 800 x 600 screen resolution
	1	One USB 2.0 port available per unit
	Standard (9580-C-3)	76.19 mm horizontal
Field of view		57.15 mm vertical
rield of view	DPM (9580-DPM)	44 x 44 mm
	HD (9580-DPM-HD)	33 x 30 mm
	Standard (9580-C-3)	1D = 4.0 mils (0.10 mm)
Minimum cell size	DPM (9580-DPM)	2D = 5.9 mils (0.15 mm)
	HD (9580-DPM-HD)	2D = 2.0 mils (0.05 mm)
		5 million pixels
Camera		Object distance: Contact
III. mada aki c		
Illumination	I	Red dome (660 nm)
Environmental	Ambient temperature range	Operating: 4 to 46°C, Storage: -20 to 60°C
specifications	Ambient humidity range	Operating: 20% to 80% (with no icing or condensation),
	7	Storage: 20% to 95% (with no icing or condensation)
Communications		USB 2.0 A plug to Mini-B plug cable, 2 m
Power supply		USB powered 5 VDC at 400 mA
117	Unpackaged standalone	Approx. 0.64 kg
Weight		
	Shipping weight	Approx. 1.81 kg (includes all cables and other items packaged in shipping box)
Dimensions		215.9 x 139.7 x 120.6 mm (H x D x W)
Calibrated Conformance Test Card (Included with system)		Included with 9580-C-3: EAN / UPC Calibrated Conformance Standard Test Card Included with 9580-DPM: EAN / UPC Calibrated Conformance Standard Test Card
		Included with 9580-DPM-HD: Data Matrix Calibrated Conformance Standard Test Card
Safety standards		FCC, CE, UL
V. C. A. COMPONIC		

^{*} Contact OMRON for a complete list of supported ECC-200 (Data Matrix) codes. CC=Composite Components

Dimensions (Unit: mm)



MEMO
·
<u>:</u>
:
·

Terms and Conditions Agreement

Read and understand this catalog.

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranties.

- (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.
- (b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions.

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Parts included in this catalog are designed exclusively for use with industrial machines. Because this product does not fall under the scope of the Electrical Appliance and Material Safety Act, it cannot be connected to power supply equipment in houses, shops, small offices, etc. for use. Contact an OMRON sales representative for more information.

- ·EtherNet/IP™ is a trademark of ODVA.
- ·QR code is the registered trademark of DENSO WAVE.
- ·Windows is registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- ·Intel and the Intel logo are trademarks of Intel Corporation in the U.S. and/or other countries.
- Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.
- ·The product photographs and figures that are used in this catalog may vary somewhat from the actual products.

Note: Do not use this document to operate the Unit.

OMRON Corporation Industrial Automation Company Kyoto, JAPAN

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2018-2019 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

CSM_2_5_0719 Cat. No. Q263-E1-02

0319 (1118)